

CORRECTION

There are some mistakes in the instruction book, so correct as below.

Page	INCORRECT	CORRECT
P.14 Step ⑧-④	The current setting for this option, <u>36</u> , should be changed if there is interference. Select a channel that is far from <u>36</u> .	The current setting for this option, <u>38</u> , should be changed if there is interference. Select a channel that is far from <u>38</u> .
P. 58 Connection	Preset CH <u>36</u>	Preset CH <u>38</u>